

Base

### Pool Component Installation Manual

**Assembling the Pool** 

**D**Part No. **1920746** 





of using patio

stones you can

make **crushed** 

limestone pads. Dig a  $12^{"} \times 12^{"} (30 \times 12^{"})$ 

fill the hole with

packing it down

with water as you

Bend the first 1/8"

hard. Spray the crushed limestone

pack it down.

Hint:

30 cm) square hole

2" (5 cm) deep and

crushed limestone,

If you want, instead

Note:


## A. Assemble your Pool Base

#### 1. Lay out the Base Plates and Bottom Rails

- a. This step is optional: Place sheets of 1" or 1-1/2" (25 or 38 mm) thick Styrofoam on the ground over the complete area where the pool is to be constructed. Place the bottom rails and base plates on top of the Styrofoam. Do not leave any gaps between the ends of the bottom rails. Using the inside face of the base rail as a cutting line, cut the Styrofoam with a knife. Prior to removing the Styrofoam from inside of the pool perimeter, number each piece with a marker to make reassembling them fast and easy. Remove all of the Styrofoam from under the base plates and from inside of the pool (the Styrofoam trimmed off outside the rails can be discarded). Neatly stack the Styrofoam removed from inside of the pool it will be required later after the pool wall has been installed in Section 3, not before.
- b. Place the base plates equally spaced around the perimeter of your foundation. If you are using the optional patio stones, place one base plate on each stone.
- c. Slide the curved bottom rails together with the base plates.
   Leave a 1/2" (13 mm) gap between the ends of the bottom rails.

#### 2. Spread out Brick Sand

a. Spread a layer of fine brick sand (no pebbles) over the foundation area, 2" (5 cm) deep. Use a rake to make the brick sand flat and smooth. Instead of brick sand, you can use the sheets of Styrofoam previously cut out in Step 1a but you must wait until the pool wall has been installed (Section 3) before using this option. When you reassemble the sheets in the centre of the pool, join them with duct tape along the whole length of each seam.



(3 mm) of the end of the bottom rail slightly with a pair of pliers to make sure the rail doesn't slide out of the base plate when the pool wall is installed.



#### **Remember:**

Spread brick sand or sheets of styrofoam out over the entire pool foundation area inside the base rails. This provides a protective surface for the pool liner to rest on. Pools with a styrofoam layer **must** still have a cove.



#### Hint:

Bring the following items onto the pool foundation **before** you start uncoiling the pool wall: the **pool liner**, some extra **brick sand** to make the cove in Step 5, and a **ladder** to climb out after the wall is assembled.




#### Caution:

**Do not** attempt to install the pool wall in the wind. Wait for a calm day.



Remember: For best results, mount the skimmer on the **downwind** side of the pool (that is, directly across from the most common wind direction).



#### Hint:

Secure the slotted tube connector to the wall with a piece of duct tape after installation to prevent it from lifting off the wall. **Pool Component Installation Manual** 


## Assembling the Pool Wall & Liner


## A. Assemble your Pool Wall

#### This section is for Round and Oval pools (Round pools are shown).

#### 1. Set the Pool Wall in place

- a. Wait for a calm day. **Do not** attempt to install the pool wall in the wind.
- b. Unpackage the coiled pool wall and stand it on a piece of cardboard or plywood at the centre of the pool. The cut-outs for the through-thewall skimmer should be towards the top of the wall. Look for a "THIS WAY UP" label and arrow.
- c. Start uncoiling the wall, guiding the bottom edge into the curved bottom rail. The starting end of the wall **must** be positioned **over a base plate**, and the skimmer and return holes should be positioned where the pump and filter will be.
- d. Set lengths of slotted tube onto the top edge of the wall as you uncoil it and join the slotted tubes with connectors as you go, leaving a 1/2" (13 mm) gap between each. **Make sure** the gap is directly above the base plate (this applies to round pools, oval pools and Gibraltar Style pools). (If you have a beaded pool liner, set lengths of **liner retainer** on the top edge of the wall first, then the slotted tubes and connectors.)







e. Work around the foundation until the entire pool wall is uncoiled into the bottom rails and the top edge is covered with slotted tubes and connectors (and beaded liner retainers if you have a beaded pool liner).

#### 2. Join the Ends of the Pool Wall

a. Line up the holes in the two ends of the pool wall.




b. To line up the holes, make the circle bigger or smaller by nudging the base plates in or out with your foot.






#### **Remember:** The bolt heads must be toward the inside of the pool. Cover the bolt heads with duct tape.

- c. Join the ends of the pool wall with a bolt and nut through each hole. Place each bolt head towards the **inside** of the pool and each nut towards the **outside**.
- d. Tighten each bolt and nut securely.
- e. Cover the seam and bolt heads on the inside of the pool wall completely with 2" (50 mm) duct tape.







#### !>

**Hint:** Stick a screwdriver through two of the holes to help line up the ends of the wall.

#### 3. Make sure the Pool Wall is Level


a. Use a length of string and a line-level to check across the top edge of the pool wall to see if it is level. Check the wall in several different directions. The wall **must** be level. If the level is off by more than 1" (25 mm) across the diameter of the pool, take the wall apart and level the foundation again.






#### 4. Make sure the Pool Wall is Round

a. Using a tape measure, measure across the circle at each base plate. The pool wall **must** be round within 1" (25 mm) (all of the measurements must be within 1" (25 mm) of each other). Adjust the circle by nudging the base plates in or out with your foot.



b. Adjusting the pool to the proper shape may cause the base rails and base plates to slip out of alignment a little. Recheck all of the base plates to make sure each one is centred where the base rails meet.



#### 5. Install the Styrofoam Sheets (optional)

a. If you chose the option of using Styrofoam **instead** of brick sand, you can now install the sheets of Styrofoam previously cut out in Step 1a. Reassemble the sheets in the centre of the pool and join them with duct tape along the whole length of each seam. Remember to wait until the pool wall has been installed in Section 3 before installing the Styrofoam.



#### Caution:

The pool **must** be level within 1" (25 mm) across the diameter. A pool that is not level is dangerous and may collapse.



#### Remember:

The cove is an important part of the pool structure. Take your time to make a complete, full-size cove.

## (!)

#### Caution:

The "Wall-Saver" gasket is important for protection against corrosion. Failure to install this gasket properly on the cutout for 6" or 12" skimmers may void the warranty of your pool wall. If the gasket is damaged, get a replacement from your pool dealer. Note: The "Wall-Saver" gasket is not required or provided for walls using 14" skimmers.

## $\diamond$

#### Hint:

If possible, unfold the liner on the grass one to two hours before installation. **Be careful** not to leave the liner too long or you may damage the grass.

#### 6. Make a Cove

- a. Make a curved cove about 6" (15 cm) high and 8" (20 cm) wide all around the bottom of the pool wall on the inside.
- b. Use fine earth or brick sand to make the cove, and pack it firmly into shape.


#### 7. Install the "Wall-Saver" Gasket 🗊


- a. The Wall-Saver gasket provides a water-tight seal around the skimmer cut-out for the through-the-wall skimmer. Gently spread apart the two layers of the gasket and insert it into the skimmer cutout so that it sandwiches the wall. Be very careful not to tear or damage the seam in the gasket or the gasket may leak. Take extra care not to cut or damage the gasket when you are installing the skimmer later. If the gasket is damaged, you **must** get a replacement from your pool dealer.
- Note: The "Wall-Saver" gasket is not required or provided for walls using 14" skimmers.


## B. Install your Pool — Liner


#### 1. Set the liner in place


- a. Open the carton. **Do not** use anything sharp to open the carton.
- b. Unpack and unfold the liner and spread it out in the sun to warm it up. Inspect all the seams and surfaces for holes.











 $\diamond$ 

#### Hint:

To smooth out the wrinkles in step 2(c), use a **vacuum** 

cleaner: block the skimmer outlet with cardboard and tape and put the vacuum hose through the skimmer return hole, between the liner and pool wall. Seal the hole with tape and keep the hose 4" to 6" (10 to 15 cm) above the sand cove so you don't suck up any sand. Start the vacuum and run it until most of the wrinkles are gone. Then, stop the vacuum and add 1" (2.5 cm) of water to the pool. Finally, remove the vacuum hose and unplug the skimmer hole.

 $\land$ 

Remember:

**Do not** trim off the excess liner. (If the liner ever needs to be removed, trimming the liner will make re-installation very difficult.) Instead, roll up any excess liner and tape it in place near the top of the pool wall.


- c. Spread out the liner. Follow the instructions supplied with the liner for the correct orientation of the smooth side. The curved seam should be centred on the cove at the base of the wall. The other seams will form straight lines across the bottom of the pool.
- d. Smooth out all the wrinkles in the bottom.

#### 2. Fasten the Liner in place (Overlap Liner only)

This step applies only if you have an **Overlap** Liner. See the next page if you have a **Beaded** Liner or **V-Bead Liner**.


18

- a. Lift the sides of the liner and drape them over the top of the pool wall. If you have a 52" (132 cm) high pool, pull the liner up until there is 2" (5 cm) overhang; if you have a 48" (122 cm) high pool, pull the liner up until there is 6" (15 cm) overhang.
- b. Fasten the liner to the top of the wall with plastic coping. Let the liner hang slack for now. **Do not** pull the liner tight.
- c. Start filling the pool with water. As the pool fills, work out all the wrinkles and smooth the liner to the wall. Remove the plastic coping around the top edge of the wall **one piece at a time** and adjust the liner. Keep smoothing out the wrinkles.





- 3. Trim the Plastic Coping and Roll Up the Excess Liner a. After all the wrinkles in the liner are removed.
  - a. After all the wrinkles in the liner are removed, trim any extra length of plastic coping so there is no overlap.
  - b. Roll up any excess liner hanging below the plastic coping and tape it in place near the top of the pool wall. **Important: Do not** trim off the excess liner.




#### 4. Fasten the Liner in place (Beaded Liner only)

This step applies only if you have a **Beaded Liner**. See the previous page if you have an **Overlap Liner** or below if you have a **V-Bead Liner**.

- a. Lift the sides of the liner and insert the beaded edge into the liner retainer on the top edge of the pool wall.
- b. Start filling the pool with water. As the pool fills, work out all the wrinkles and smooth the liner to the wall.

#### 5. Fasten the Liner in place (V-Bead or J-Bead Liner only)


This step applies only if you have a **V-Bead or J-Bead Liner**. See steps 2 and 3 if you have an **Overlap Liner**, or step 4 if you have a **Beaded Liner**.



 a. Remove the slotted tubes and connectors from the top edge of the pool wall.
 Important: do not remove all of the slotted

tubes at once; remove only **two** lengths of slotted tube at a time.

- b. Hook the V-bead or J-Bead over the edge of the pool wall.
- c. The space between the ends of the slotted tubes at the tops of the locations where the verticals will be attached, should be about 1/2" (13 mm). If you have a Gibraltar Oval System, refer to page 2-6, step 2 in the Gibraltar manual.
- d. Replace the two lengths of slotted tube and connectors.
- e. Repeat steps (a) to (d) until you have gone around the entire pool and finished attaching the pool liner in place.



f. Start filling the pool with water. As the pool fills, work out all the wrinkles and smooth the liner to the wall.

#### 6. Proceed to Section 4

a. Continue with Section 4 to finish assembling your pool.

# SECTION

**Pool Component Installation Manual** 

## Installing the Top Rails & Verticals

## A. Attach your Verticals and Top Rails


#### 1. Continue filling your Pool

- a. Continue filling your pool with water. Do not put in more than 12" (30 cm) of water until the top rails and vertical columns are all attached.
- b. Keep working on the top rails and vertical columns while the pool fills.


#### See the drawing on the next page for an overview of all the parts used to install the verticals, top rails and top connectors.

#### 2. Install the Vertical Columns

- a. Line up the bottom of one vertical column (key 1) with the two small tabs on one base plate (key 2). The tabs must be on the **inside** of the vertical column.
- b. Line up the screw holes and fasten with one self-tapping screw on each side (key 3).




- c. Hook a top plate (key 4) over the top edge of the pool wall (key 5). Place the top plate down over the top of the vertical column with the tabs on the **outside** of the column. Make sure the vertical column is straight up and down.
- d. Line up the screw holes and fasten with one selftapping screw on each side and one on the front (key 6).
- e. Repeat the last four steps for each of the vertical columns around the pool wall.



Use the ridges in the pool wall to make sure the vertical column is straight up and down.

#### Overview of Vertical, Top Rail and Top Connector Assembly




No Diving or Jumping. Observe all Safety Rules.


#### 3. Install the Top Rails


- a. Place a top rail (key 7) with one end on top of the top plate. The side of the top rail facing the centre of the pool should be close to the pool liner and pool wall. The side of the top rail facing the outside of the pool will form a large overhang.
- b. Line up the holes as shown. Fasten through the two oval holes into the holes marked 'A' in the top plate below with two self-tapping screws (key 8).
  Do not tighten the screws yet. Leave the screws slightly loose until all the top rails are in place.
- c. Repeat the last two steps for the other end of the top rail.
- d. Repeat steps (a) to (c) to install the rest of the top rails around the top of the pool wall.
- e. Make the pool settle into a perfect circle by pushing the top of the pool wall **vigorously** inward at each vertical (this will help make the bottom of the pool wall shift into a perfect circle).
- f. Adjust all the top rails to line up evenly with each other.
- g. Tighten all the screws on all of the top rails.

#### 4. Install the Top Connectors

- a. Line up the connector (key 9) above the ends of two top rails.
- b. Hook the small tabs protruding from the underside of the connector onto the inside edges of the top rails and hold them firmly in place. Pull the other end of the connector down into place under the top rails by **gently** stretching it across and down, as shown in diagrams 6 to 9.









#### (!)


#### Caution: Be sure to spread the sides of the lower half connec-


tor before stretching it across the top rails or the connector may be damaged.


## $\bigcirc$


**Note:** If necessary, the plug covering the screws can be removed by prying it out with a knife. Be careful not to damage the edges of the plug.


- c. Prior to installing the connector, knock out the holes shown in diagram 10.
- d. Push the lower part of the connector in towards the vertical column and line up the two screw holes in the lower portion of the connector with the two holes in the vertical column. Fasten the connector in place with two self-tapping screws (key 3). **Important:** Tighten the screws **only** until a snug fit is obtained. **Do not over-tighten.**
- e. For oval pools only: At the transition points only, where the end rail meets the side rail, make sure the side rail lines up properly with the end rail. If it doesn't line up, the connector will appear crooked from above (see diagram 12). If the connector isn't centered between the rails, temporarily remove the connector and loosen the screws on the side rail. Shift the side rail in or out from the center of the pool until the connector can be properly centered between the rails (see diagram 13).
- f. Install the connector clip (key 10) by lining up the circular ring on the clip with the circular ring on the connector and applying pressure. The clip will snap into place. (see diagram 14). If the connector clip does not snap in, slightly loosen the screws.
- g. First insert the tab on the left of the logo insert (key 11) into the opening on the top of the connector designed for the logo insert. Bend the insert slightly and insert the other tab into the opening on the other side of the connector. Press down on the insert to ensure a proper fit.
- h. Repeat the last seven steps for the rest of the top connectors.













#### Important:

The pool wall may bulge and shift a little while filling with water. This is normal.



#### Note:


For Footcover installation on a vertical over a buttress, it may be necessary to modify the front clip of the Footcover. If the Buttress Upright behind the vertical blocks the front clip from being inserted, file it down until insertion is possible.

#### 5. Install the Foot Cover (Optional)

- a. If the pool has been supplied with footcovers, the centre tab on the vertical will need to be knocked out prior to installation.
- b. Place the foot cover on top of the base plate (key 12). Slide the foot cover towards the pool wall until the side clips and front clip snap into the vertical column (key 1).

**Important:** Ensure that the side clips snap into the cutouts for the bottom rails.

c. Repeat the last step for each of the vertical columns around the pool wall.



## **B. Fill your Pool with Water**

## (!)

#### Caution:

Before anyone uses your pool, read and follow all the **Safety Rules** in Section 1. This pool is **not** for diving or jumping.

#### 1. Finish filling the pool

a. Fill the pool with water to 2" (5 cm) below the lowest opening. Next, follow the installation instructions for your skimmer.