

POOL-N-BEACH CABANA LOUNGE OWNER'S MANUAL

Important information enclosed in this manual please read these materials prior to assembling and using this product. Keep for future reference.

For questions on assembly, parts or warranty, contact the experts at Sportsstuff. DO NOT RETURN this product to the store!

Contact us TOLL FREE: 888-814-8833 (USA) (8am-5pm, CST Monday-Friday)

Congratulations on your new product purchase! Sportsstuff prides itself in making the most innovative inflatable products on the planet. Your high performance product is designed to enhance your outdoor water activities.

Product Name Model # Inflated Dimensions Capacity Weight Limit
Pool-N-Beach Cabana 54-1900 80" x 54"/200 x 135cm 2 400 lbs
Lounge



To lessen your risk of serious injury or death, follow these rules:

IMPORTANT SAFETY INSTRUCTIONS READ AND FOLLOW ALL INSTRUCTIONS

- Please inspect the unit before and after each use.
- Read the owner's manual carefully before using your Sportsstuff product.
- This product is NOT for use by children under 6 years of age.
- Not a lifesaving device
- Never leave children unattended
- Use only under competent supervision
- Do not use under the influence of drugs or alcohol.
- Intended only for use in pools, very calm waters away from boats and other hazards, indoors, or flat outdoor land surfaces such as beaches and patios.
- This product is not to be used in the water by non-swimmers without a USCG approved life vest.
- Do not stand or kneel on this product at any time.
- Use only in the sitting or reclined position.
- Make sure the product is properly inflated with the air valve closed tightly.
- Do not use this product if it is damaged or leaking air.
- Do not exceed the manufacturer's recommended person capacity for this product.

- This is not a towable tube.
- Do not use this item as a baby or pet float.
- Do not use this item as a fishing vessel.
- Store this item deflated and indoors in a cool, dry place.
- Use at your own risk!
- Always stay awake and aware when using this item.
- Do not swim underneath this unit at anytime.
- Monitor and adjust bladder pressure on warm days and in direct sunlight.
- Do not use this unit when it is under-inflated. The risks involved with this could include entrapment which may result in death or serious injury.

SAVE THESE INSTRUCTIONS

RELEASE OF LIABILITY:

By assembling and inflating this product, you agree that you have read and understand the entire Sportsstuff's product manual, including all instructions and warnings contained in that material prior to using this product. You additionally agree that you will ensure any additional or subsequent users of this product will read and understand the entire owner's manual. Misuse or improper use of this product could result in risks, dangers and hazards which may result in serious injury or death. The risks and dangers that may be encountered through the improper use of this product can be avoided by reading and following the warning guidelines listed within the owner's manual and by proper use of this product. Your assembly and use of this product shall be evidence of your agreement, to the fullest extent permitted by law, to properly follow the instructions and abide by the warnings set forth within the product manual. Your assembly and use of this product shall also constitute a release, to the extent permitted by law, by you and by any third party permitted by you to use, in any manner, this product, to Sportsstuff from any and all liability for any loss, damage, injury and/or expense that you or any user of this product may suffer as a result of the use of this product. This release shall extend to any loss, damage, injury or expense due to any cause whatsoever, including negligence or breach of contract on the part of Sportsstuff and/or any party participating in the design and/or manufacture of this product. The terms of this release shall be effective and binding upon you, your heirs, next of kin, executors, administrators, assigns and representatives. Your assembly and use of this product shall constitute your agreement to assume and accept any or all known or unknown risks of injury to you and/or to third parties through the use of this product. Sportsstuff and related parties have not made and hereby expressly deny any oral or written representation and/or warranty, including warranty for a particular purpose, other than what is set forth herein and in the Sportsstuff's owners manual.

The Pool-N-Beach Cabana Lounge includes:

- LP1 Double Action Hand Pump Included
- Double Stitched Nylon Full Cover With Zipper
- 3 Flat Webbing Foam Handles
- · Detachable, Adjustable Cabana Shade with air vents
- · Padded Valve Cover
- PATENTED Speed Safety Valve for Fast Inflation and Deflation
- Single Chamber Heavy-Gauge PVC Bladder

^{*} Please note the Pool-N-Beach Cabana Lounge is not a towable.

ASSEMBLY AND INSTALLATION:

- 1. Locate the valve on the main tube (You may have to open valve cover on the nylon cover).
- 2. Be sure zipper on the cover is completely closed.
- 3. Inflate main tube until it is firm and the cover is wrinkle free and taut. (Please see the INFLATION section below for proper inflation instruction).
- 4. Close valve completely. Fasten velcro on valve cover.
- 5. Carefully layout cabana hood portion.
- 6. Attach each pole portion to its neighboring pole fitting. Ensure that all pole sections are completely connected and secure.
- 7. Insert the two ends of the assembled pole frame into the sleeves on each side of the lounge's backrest so that the printed side of the hood will face the sky when the hood is completely attached.
- 8. Fasten the buckles on the back of the hood portion to the back of the lounge.
- 9. Locate the rope and hook on each side of the hood. Pull down rope/hook on each side of the hood and fasten the hook to the metal loop on the top of the lounge.

INFLATION:

Proper inflation is the key to the optimum performance of this product. The PVC bladder is designed to fit snugly in the cover, and there should be very few wrinkles in the cover when the tube is properly inflated.

IMPROPER INFLATION



PROPER INFLATION



Photo "A" shows a tube severely underinflated. Note how the adult standing on the tube sinks down into the tube.

Photo "B" shows a tube properly inflated. Note how the adult standing on the tube barely sinks down into the tube. When properly inflated, all features of the product will remain sturdy and perform better, prolonging the life of the unit.

Proper inflation is the key to the optimum performance of this product. The PVC bladder must expand and should be firm to the touch.

Inflation Maintenance:

Finally, it is not enough to simply fill it up and go! It is important to monitor the amount of air in this product as heat will cause the bladder to expand, possibly causing damage to the seams or I-beams. If you leave a full tube sitting in the sun for any length of time, it will expand. Either store it in the shade, or let some air out. Don't let it sit on the beach, dock, or boat full of air! At the same time, if it is stored out of the sun in a cool place, you may need to add air. Check and adjust inflation levels each time you use your tube. You'll have more fun, and your products will last longer.

Your Sportsstuff product is equipped with the following type of valve:



Speed Safety Valve - Pulls out for fast inflation/deflation, then can be pushed in flush with the tube. For use with standard electric pumps, shop vac, wet vac, leaf blowers, vacuum with a 2-way switch for fast inflation/deflation, and hand/foot pumps like the one included.

LP1 DOUBLE ACTION PUMP INSTRUCTIONS:

Read all pump instructions prior to use!

An LP1 Double Action Hand Pump is included with your Pool-N-Beach Cabana Lounge. This pump is sufficient to fully inflate the product properly. It is also equipped with several different hose nozzles for use with different types of valves. One of the attachments will closely fit the speed safety valve on the Pool-N-Beach Cabana Lounge. Use this nozzle for fast and easy inflating/deflating.

Please note: This pump is a double action pump which means it will inflate/deflate on both the up and down strokes of the pump handle. The pump will inflate when the hose is connected to the attachment point marked "inflate" and will deflate when connected to the attachment point marked "deflate" on the pump. This pump may also be used as a bilde.

Other possible air pumps to use are:

- 110v electric: 2.5 psi (model #57-1504A) or 3.0 psi (model #57-1508)
- Hand/foot pump specifically for towables: LP1 (model #57-1003)
- 12v pumps (model #57-1510) can also be used but a their maximum output is only .8 psi so a secondary pump such as the Sportsstuff LP1 hand pump (model #57-1003) will need to be used.
- Leaf Blower
- Vacuum with two-way switch

Various types of air pumps are available from Sportsstuff at 1-888-814-8833 or online at http://www.sportsstuff.com

Important:

- 1. This high-volume pump is intended to inflate such objects as air-beds, inflatable boats, towables, etc. This product is not intended for filling tires.
- 2. Not for use by children.
- 3. If pump is damaged in any way, contact Sportsstuff for prompt parts replacement.

Operation:

Inflating

- 1. Locate inflation valve on your product. Open valve.
- 2. Fasten the inflator hose attachment point to the inflation port on the pump. Attach the nozzle of your choice to the end of the inflation hose.
- 3. Insert hose/nozzle into valve.
- 4. Secure the base of the pump with your feet. Pull up and down on the pump handle until the product is firm to the touch and cover is taut.
- 5. When product is fully inflated, remove hose from valve, and close the valve.

Deflating

- 1. Open the valve completely to release air.
- 2. Unfasten inflation hose from the inflation port and attach to the deflation port.
- 3. Using the appropriate nozzle for the product's valve, insert nozzle/hose into valve.
- 4. Secure the base of the pump with your feet. Pull up and down on the pump handle until the product is deflated.
- 5. When complete, remove hose from the valve, close valve, and store the pump until next use.

MAINTENANCE:

Very little care is required for the bladder or cover:

- You may clean your product using soap and water or mild detergent.
- · Never use strong cleaning agents.
- The product, when clean and dry, can be deflated and stored in a cool, dry area out of direct sunlight.
- · To deflate, simply unfasten the valve from the base.
- Avoid storing this product in areas of extreme temperatures and please take precautions against animals and rodents.
- Bright colored fabric covers used on the product may bleed or fade when initially wet. Protect all boat and car interiors and all other surfaces from possible staining.

GENERAL TROUBLE SHOOTING GUIDE:

Symptom: Product won't hold air.

Solution: Check to see that the speed safety valve is fastened properly. Re-install valve if needed. Check to see if the product was inflated fully from the beginning. If you suspect it wasn't inflated fully, add more air. PVC Repair Adhesive is available from Sportsstuff at www.sportsstuff.com or 888-814-8833 for small hole or seam repairs.

Symptom: Product inflates but doesn't become firm.

Solution: Please check to make sure it was inflated firmly with a high volume air pump or compressor adapter. If you are sure you inflated it properly, fully assess it for a leak or re-install the speed valve. If a leak is detected, the bladder may be patched by using Sportsstuff PVC Adhesive which can be purchased directly from Sportsstuff.

Symptom: Cover is very loose (Applies only to products with covers).

Solution: Please check to make sure that your product is inflated fully and the tube is in place. The cover should fit snugly over the well-inflated tube. If the cover remains loose, add more air. If you notice water in between your tube and cover more air must be added to the tube.

REPLACING PRODUCT PARTS:

If a leak or problem is suspected with your tube, locate the valve and deflate the item and remove the inflatable PVC bladder to inspect possible problem areas. Contact Sportsstuff warranty department for prompt parts replacement if a problem is located. For non-warranty parts replacement, follow the same procedure. When a replacement is received, follow the steps below:

- 1. Unfold the cover and lay the bladder out.
- 2. Locate the bladder and the inflation valve. Open the zipper on the cover and place the PVC bladder inside the cover of the product.
- 3. Line up the valve with the valve opening in the cover.
- 4. Refer to steps 1-3 in the above ASSEMBLY AND INSTALLATION section.

USE:

Once product is properly inflated this float can be used in pools, very calm waters away from boats and other hazards, indoors, or flat outdoor land surfaces such as beaches and patios.

A WARNING! GENERAL USE AND SAFETY: A

- When using a Sportsstuff product, you are engaging in an exciting recreational activity with inherent risks. Act responsibly and only use your product with the awareness of and willingness to accept the risks involved.
- Read all instructions and warnings provided to you in this owner's manual and those printed on the product. Do not discard this manual.
- As in any recreational activity, reckless use, misuse, inexperience and/or neglect of the proper equipment used may result in serious injury or death.
- Visually inspect the product before each use. If the product is torn, leaking, or damaged in any way, do not use. Contact Sportsstuff for prompt parts replacement.
- This product is NOT for use by children under 6 years of age. Children 6 years and older should only use this product under the careful supervision of an adult.
- Please note this product is not a life saving device.
- Sportsstuff products are NOT intended for rental use.
- Do not consume alcohol or other drugs while using this product. Even small quantities of alcohol and other drugs can impair judgment, balance, and coordination which can greatly affects one's performance.
- Make sure all non-swimmers are wearing a U.S. Coast Guard Type III (PFD) approved life vest at all times.
- Be conscious of the weather conditions as weather changes can occur very quickly.

WARRANTY POLICY:

Sportsstuff warrants, to the original purchaser only, that their high performance products, when used for normal recreational purposes, are free from defects in material and workmanship for a period of ninety (90) days from the date of purchase. This warranty does NOT cover: products for rental, for hire and other uses not considered for normal recreational purposes; nor punctures, cuts, abrasions in normal use. For prompt parts replacement or warranty issues, contact Sportsstuff directly at 888-814-8833. Replacement parts are shipped within 48 hours of notification Monday through Friday. Do not return to your dealer. (USA ONLY.) This warranty is only valid in the USA.

If you have any questions about any Sportsstuff, Inc. product, replacement parts or locating a dealer in your area, contact us at:

Sportsstuff Inc. 11213 E Circle Suite A Omaha, NE 68137

Fax: 402-592-1354

Toll Free: 888-814-8833 Tel: 402-592-9085

E-mail: customercare@sportsstuff.com

Warranty registration is available on-line at: http://www.sportsstuff.com

Prior authorization is required for returned merchandise. No credit will be given for a product that is sent back without prior authorization from Sportsstuff, Inc. After receiving an authorization number, please ship returned products to the following address:

Sportsstuff, Inc. Return Center 11213 E Circle Suite A Omaha, NE 68137 (Please label package with RA #)

