


DARTBOARD ASSEMBLY INSTRUCTIONS



Model NG1041D

Challenger Manufacturing

We work around the clock and around the globe to ensure that our products maintain the highest possible quality. However, in the rare instance that your product is defective or missing parts, **PLEASE DO NOT RETURN TO THE STORE**, and contact us through one of the following methods:

Toll Free: 800-759-0977

Mail: Challenger Manufacturing

Customer Service Department













1745 Wallace Ave.

St. Charles, IL 60174

Please have your model number and part number available for Customer Service Representatives prior to calling. These numbers are available on the product packaging as well as in this owner's manual.

IMPORTANT! PLEASE READ THIS MANUAL IN ITS ENTIRETY BEFORE ASSEMBLING YOUR PRODUCT.

PARTS IDENTIFIER (Not to Scale)

#1  BRISTLE DARTBOARD (1 PC)	#2  1.3" SCREW (32mm - 2 PCS)	#3  2" SCREW (50mm - 4 PCS)	#4  WASHER (15mm - 6 PCS)	#5  PLASTIC ANCHOR (2 PCS)	#6: PRE-ASSEMBLED  TRIANGLE SHAPE BRACKET (2 PCS)
#7: PRE-ASSEMBLED  RUBBER BUMPER (3 PCS)	#8: PRE-ASSEMBLED  BUMPER NAIL (3 PCS)	#9: PRE-ASSEMBLED  DARTBOARD MOUNTING BRACKET (1 PC)	#10: PRE-ASSEMBLED  SMALL MOUNTING BRACKET BOLT (2 PCS)	#11: PRE-ASSEMBLED  SMALL MOUNTING BRACKET NUT (2 PCS)	#11: PRE-ASSEMBLED  DARTBOARD MOUNTING SCREW (1 PC)

Additional equipment required:



STUD
FINDER



LEVEL



PHILLIPS
SCREWDRIVER



ELECTRIC
SCREWDRIVER



ELECTRIC
DRILL and DRILL BIT



HAMMER



MARKING
PENCIL



TAPE
MEASURE

Electric Screwdrivers may be helpful during assembly; however, please set a low torque and use extreme caution because screws may be stripped or overtightened if the electric screwdriver's torque is set too high.

Some figures or drawings may not look exactly like your product. Please read and understand the text before beginning each assembly step.

Please see Parts List at end of manual for Part Numbers when ordering parts. For replacement parts please call 800-759-0977.

WARNINGS!

READ AND FOLLOW ALL ASSEMBLY, INSTALLATION, AND SAFETY INSTRUCTIONS CAREFULLY. AT LEAST TWO ADULTS ARE NEEDED FOR THE INSTALLATION OF THIS CABINET.

DARTS ARE NOT A TOY FOR USE BY CHILDREN. THEY MAY CAUSE SERIOUS OR FATAL INJURY. KEEP OUT OF REACH OF CHILDREN. DO NOT USE WHEN ANY PERSON OR ANIMAL IS IN THE VICINITY OF THE INTENDED FLIGHT PATH OF THE DART OR TARGET AREA.


DARTBOARD INSTALLATION INSTRUCTIONS

Cabinet Mounting Hardware for mason, concrete, or brick walls is not included. Please purchase the necessary hardware from your local hardware store, and be sure to tell the hardware person the exact type of wall to which you are mounting the cabinet. Ask them to provide hardware that will support up to 60 pounds of weight. It is very important to use correct hardware for your particular wall in order to avoid injury or damage. The following instructions concern mounting your Dartboard Cabinet to a standard drywall or plaster wall with wood studs. There are two options for attaching your Dartboard Cabinet to a standard drywall or plaster wall.

OPTION 1:

Step 1: Two Triangle Shaped Brackets (#6) have been mounted to the top of your Dartboard Cabinet approximately 16 inches apart (same distance as wall studs). Have someone hold the Cabinet (without the Bristle Dartboard (#1)) to the desired place and height (distance from bull's eye to the ground should measure 5 feet 8 inches) on your wall, and use a pencil to mark the places that the holes will be drilled into the wall. It is critical that the holes be drilled deep enough to ensure the Plastic Anchors (#5) is flush with the wall.


Figure 1



Step 2: Select a drill bit that is roughly the same diameter as the Plastic Anchors (#5) included in the hardware package. Once the holes have been drilled, use a hammer and tap the Plastic Anchors (#5) into the hole. Once the Plastic Anchors (#5) have been inserted, you may screw the 1.3" Screws (#2) into them.

Step 3: Once both 1.3" Screws (#2) have been inserted into the wall, hang the Cabinet (without the Bristle Dartboard (#1)) using the Triangle Shaped Brackets (#6) onto the wall. Next, hang the Bristle Dartboard (#1) onto the Dartboard Mounting Bracket (#9) that is pre-installed on the inside of the Cabinet.

Figure 2




You are now ready to play!

OPTION 2:

Step 1: Four holes have been pre-drilled inside the Dartboard Cabinet, approximately 16 inches apart. Have someone hold the Cabinet (without the Bristle Dartboard (#1)) to the desired place and height (distance from bull's eye to the ground should measure 5 feet 8 inches) on your wall, and use a pencil to mark the places where the 2" Screws (#3) will be drilled into the wall. Remove the Cabinet from the wall and double-check the pencil marks to ensure that the holes will be drilled into the wood studs.


Figure 3



Step 2: Once you are certain the marks are at the proper height and they are located at the wood studs, have someone hold the Dartboard Cabinet (without the Bristle Dartboard (#1)) against the wall. Make sure that the four holes in the Cabinet are lined up with your previous pencil marks. Now use an electric screwdriver to screw the 2" Screws (#3) with Washers (#4) directly into the wall making sure to drill into the wood studs.

Step 3: Once the Cabinet is securely fastened to the wall, you may hang the Bristle Dartboard (#1) onto the Dartboard Mounting Bracket (#9) that is pre-installed on the inside of the cabinet. To do this, slip the screw that is on the back center of the Bristle Dartboard (#1) into the opening of the Dartboard Mounting Bracket (#9).

Figure 4



You are now ready to play!

General Rules of Darts

There are many different types of dart games. Two of the most popular are "Cricket" and "01". There are numerous versions of "01", like 301, 501, 601, 801, etc. No matter which variation of the game you decide to play, the basic rules of darts remain the same. The following information includes overview of dart rules, some fundamentals, and a few tips to keep your game on target.

Players

Darts is played between two people or two teams. All players are allowed up to nine pre-game throws to warm up before the game begins. To determine who starts the game, each person (or one person from each team) throws a dart. The one closest to the bulls eye gets the first turn.

Throw Line

Players cannot let their feet cross the throw line. Should a foot go over the line during a throw the points will not count. This throw cannot be redone.

Throws

Each player throws three darts in a turn. The dart must stay on the board for at least five seconds after the last dart is thrown in order for the point to be counted. If a dart falls to the floor or sticks to another dart on the board, the points will not be counted.


Scoring

For darts that stay on the board, points are assigned based upon the ring in which it rests. The rings and their corresponding points are as follows:

The Wedge (Outer Ring) — Points equal the number that is indicated in the ring on the board.

Double Ring (The Outer, Narrow Ring) — Any number the dart hits is multiplied by 2.

Triple Ring (The Inner, Narrow ring) — Any number the dart hits is multiplied by 3.



Bull's Eye (The Outer Bull's Eye) — 25 Points.

Double Bull's Eye (The Inner Bull's Eye) — 50 Points.

Dart Throwing Tips

With darts, it's all about the throw. Here are some basic tips to help you hit the bulls eye.


Stance — Posture is critical in getting an even and steady throw to your target. Resist lunging forward or even lifting a foot off the ground. Try to maintain a balanced and steady stance, keeping the throw isolated to the forearm, wrist and fingers.

Throw — Try not to throw your darts. Rather, place the dart right where you want it with a smooth and steady toss that follows all the way through to the target. Keep the dart level and avoid spin as you release to create the most efficient flight to the dart board.

Standard Straight 501:

1. Each Player (or Team) will be starting with 501(301 or 1001 depending on size of teams).
2. To win the Player (or Team) will need to reduce their points to 0.
3. The last dart in the *Leg* must either hit a double or the inner section of the Bull's Eye and must reduce the score to exactly 0. Successfully doing so results in "Doubling Out" or "Checking Out".
4. Having a dart thrown that would result in a score less than zero will not count! The Player's current score will be reset to the previous turn.
5. For the purposes of Rule 3, "Bull's-Eye" counts as double 25.

***Leg:** Each game is called a Leg. 3 Legs make a Match and the winner is the player who wins 2 of 3 legs. These can be varied.



90 DAY LIMITED WARRANTY

This consumer warranty extends to the original consumer purchase of any **Challenger Manufacturing** Product (hereinafter referred to as the "Product").

WARRANTY DURATION: This Product is warranted to the original consumer purchase of a period of 90 days from the original purchase.

WARRANTY PERFORMANCE: During the above 90 day warranty period, **Challenger Manufacturing** shall repair or replace with a comparable model, and Product, or component thereof, which may prove defective under normal use and proper care, and which our examination shall disclose to our satisfaction to be thus defective, please contact our Warranty Department.

A purchase receipt or other proof of date of purchase will be required before warranty service is performed.

Other than shipping requirements no charge will be made for such repair or replacement of in-warranty Products. **Challenger Manufacturing** strongly recommends that the Product is insured for value prior to shipping/mailling

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. Challenger Manufacturing SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEMDIES: This warranty gives you specific legal rights and you may have other rights which may vary from state to state.

PARTS LIST

NG1041D

NAME: _____

Product	Description	Parts Identifier Number
NGP5610	DARTBOARD	1
NGP5611	TRIANGLE SHAPED BRACKET	6
NGP5612	RUBBER BUMPER	7
NGP5613	MOUNTING BRACKET	9
NGP5614	HARDWARE PACK	2,3,4,5,8,10,11
NGP5615	DARTS	

For replacement parts please call 800-759-0977